

Packaged Air Accessories

Coupler / Plug Sets 1/4" Body



1/4" Coupler / Plug Set
1/4" MPT
Industrial 90310 CPS15-I
Automotive 90305 CPS15-A



1/4" Coupler / Plug Set
1/4" FPT
Industrial 90260 CPS10-I
Automotive 90255 CPS10-A
ARO 90257 CPS10-ARO



1/4" Coupler / Plug Set
Coupler 1/4" FPT
Plug 1/4" MPT
Industrial 90770 CPS711-I



1/4" Coupler / Plug Set
1/4" Hose Barb
Industrial 90420 CPS7-I
Automotive 90415 CPS7-A
ARO 90417 CPS7-ARO



1/4" Coupler / Plug Set
3/8" Hose Barb
Industrial 90430 CPS8-I
Automotive 90425 CPS8-A
ARO 90427 CPS8-ARO



1/4" Coupler / Plug Set
3/8" MPT
Industrial 90280 CPS12-I
Automotive 90275 CPS12-A
ARO 90277 CPS12-ARO



1/4" Coupler / Plug Set
3/8" FPT
Industrial 90270 CPS11-I
Automotive 90265 CPS11-A
ARO 90267 CPS11-ARO



Push Lock Set
1/4" Body 1/4" Hose Barb
Industrial 90340 CPS18-I
Automotive 90335 CPS18-A
ARO 90337 CPS18-ARO



Push Lock Set
1/4" Body, 3/8" Hose Barb
Industrial 90350 CPS19-I
Automotive 90345 CPS19-A



Push Lock Set
3/8" Body, 3/8" Hose Barb
Industrial 90360 CPS20-I
Automotive 90355 CPS20-A

Push Lock Sets 1/4" or 3/8" Body



3/8" Coupler / Plug Set
1/4" MPT
Industrial 90680 CPS21-I
Automotive 90685 CPS21-A



3/8" Coupler / Plug Set
1/4" FPT
Industrial 90690 CPS22-I
Automotive 90695 CPS22-A



3/8" Coupler / Plug Set
3/8" MPT
Industrial 90300 CPS14-I
Automotive 90295 CPS14-A



3/8" Coupler / Plug Set
3/8" FPT
Industrial 90290 CPS13-I
Automotive 90285 CPS13-A



3/8" Coupler / Plug Set
3/8" Hose Barb
Industrial 90440 CPS9-I
Automotive 90435 CPS9-A

Coupler / Plug Sets 3/8" Body