

NSJH38-34 Parts List (by No.)

No.	Code	Description	No.	Code	Description
1	30105140766	Bolt M5X14	42	30700078000	O-Ring 2.15X2.0
2	20790000001	Bushing,Deflector	43	30700042000	O-Ring 45.5X2.0
3	20790010115	Deflector,Exhaust	44	21631130366	Nose
4	30105250866	Bolt M5X25	45	30106200266	Bolt M6X20
5	21630020049	Cap	46	21631540015	Guide,Safety Lever
6	21630130000	Cap, Gasket	47	21631610001	Safety Guide
7	21570230001	Metal Shim	48	21632810000	Upper Safety Lever(B)
8	21570140117	Piston Stopper	49A	21631481101	Upper Safety Lever Assy.
9	20970160100	Head Valve Spring	50	21632970301	Spring
10	30700110000	O-Ring 39.3X2.4	51	21631490101	Spring,Safety
11	21630150000	Piston Head Valve	52	30104060166	Bolt M4X6
12	30700111000	O-Ring 47.2X2.4	53	21633640001	Spring
13	30700216000	O-Ring 72.7X2.62	54	21631200000	Nail Stopper
14	21630370116	Cylinder Spacer	55	21631260015	Shaft Pin Nail Guide
15	30700121000	O-Ring 37.7X3.5	56	21633650001	Spring
16A	21630462101	Driver Assembly	57	30104040166	Bolt M4X4
17	20750250117	Seal	58	21631450001	Safety Pin
18	21630350000	Cylinder	59	30105160166	Bolt M5X16
19	30700019000	O-Ring 45.7X3.5	60A	21631521266	Safety Nose Assembly
20	30700205000	O-Ring 46.5X2.0	61	21631550015	Safety Cover
21	21570140217	Bumper	62	21633660001	Safety Cover Pin
22A	21634522050	Body Assembly	63	30700157000	Grommet 6.8X2.8
23	21630730000	Gasket	64	21632070002	Nail Guide Liner
24	21630740049	End Cap	65	21632050206	Magazine
25	30105200866	Bolt M5X20	66	21632150215	Pusher Guide
26	30605080001	Locknut	67	21632090100	Spiral Spring
27	30700079000	O-Ring 12.42X1.78	68	21632330001	Spring
28	20770900016	Valve	69	21632130201	Pusher
29	30700081000	O-Ring 12.4X2.62	70	21631750001	Fastener Stopper
30	30700002000	O-Ring 5.79X1.9	71	30803180001	Spring Pin
31	30700201000	O-Ring 6.8X1.9	72	30803080001	Spring Pin
32	20770910016	Valve Plunger	73	30104080266	Bolt M4X8
33	30700071000	O-Ring 8.79X1.9	74	21632180115	Magazine Cap
34	21630960000	Spring	75	30405120166	Bolt M5X12
35	30700080000	O-Ring 2.49X1.4	76	30900005001	Flat Washer
36	20770920000	Plunger	77	30104100866	Bolt M4X10
37	20770930016	Plunger Cap	78	21631870001	Adjusting Nut
38	21632840115	Guide, Contact Trip	79	21630830009	Belt hook
39A	21630952159	Trigger Assembly	80	30700246000	O-Ring 26X4
40	30803260001	Spring Pin	81	20970840001	Cover,Belt hook
41	20770890001	Trigger Pin	82	33425000001	C-ring

NSJH38-34 Parts List (by Code)

No.	Code	Description	No.	Code	Description
17	20750250117	Seal	53	21633640001	Spring
41	20770890001	Trigger Pin	56	21633650001	Spring
28	20770900016	Valve	62	21633660001	Safety Cover Pin
32	20770910016	Valve Plunger	22A	21634522050	Body Assembly
36	20770920000	Plunger	57	30104040166	Bolt M4X4
37	20770930016	Plunger Cap	52	30104060166	Bolt M4X6
2	20790000001	Bushing,Deflector	73	30104080266	Bolt M4X8
3	20790010115	Deflector,Exhaust	77	30104100866	Bolt M4X10
9	20970160100	Head Valve Spring	1	30105140766	Bolt M5X14
81	20970840001	Cover,Belt hook	59	30105160166	Bolt M5X16
21	21570140217	Bumper	25	30105200866	Bolt M5X20
7	21570230001	Metal Shim	4	30105250866	Bolt M5X25
5	21630020049	Cap	45	30106200266	Bolt M6X20
6	21630130000	Cap, Gasket	75	30405120166	Bolt M5X12
18	21630350000	Cylinder	26	30605080001	Locknut
14	21630370116	Cylinder Spacer	30	30700002000	O-Ring 5.79X1.9
16A	21630462101	Driver Assembly	19	30700019000	O-Ring 45.7X3.5
23	21630730000	Gasket	43	30700042000	O-Ring 45.5X2.0
24	21630740049	End Cap	33	30700071000	O-Ring 8.79X1.9
79	21630830009	Belt hook	42	30700078000	O-Ring 2.15X2.0
39A	21630952159	Trigger Assembly	27	30700079000	O-Ring 12.42X1.78
34	21630960000	Spring	35	30700080000	O-Ring 2.49X1.4
44	21631130366	Nose	29	30700081000	O-Ring 12.4X2.62
54	21631200000	Nail Stopper	10	30700110000	O-Ring 39.3X2.4
55	21631260015	Shaft Pin Nail Guide	12	30700111000	O-Ring 47.2X2.4
58	21631450001	Safety Pin	15	30700121000	O-Ring 37.7X3.5
49A	21631481101	Upper Safety Lever Assy.	63	30700157000	Grommet 6.8X2.8
51	21631490101	Spring,Safety	31	30700201000	O-Ring 6.8X1.9
60A	21631521266	Safety Nose Assembly	20	30700205000	O-Ring 46.5X2.0
70	21631750001	Fastener Stopper	13	30700216000	O-Ring 72.7X2.62
78	21631870001	Adjusting Nut	80	30700246000	O-Ring 26X4
65	21632050206	Magazine	72	30803080001	Spring Pin
64	21632070002	Nail Guide Liner	71	30803180001	Spring Pin
67	21632090100	Spiral Spring	40	30803260001	Spring Pin
69	21632130201	Pusher	76	30900005001	Flat Washer
66	21632150215	Pusher Guide	82	33425000001	C-ring
74	21632180115	Magazine Cap	8	21570140117	Piston Stopper
68	21632330001	Spring	11	21630150000	Piston Head Valve
48	21632810000	Upper Safety Lever(B)	46	21631540015	Guide,Safety Lever
38	21632840115	Guide, Contact Trip	61	21631550015	Safety Cover
50	21632970301	Spring	47	21631610001	Safety Guide